

Protoboard Breakout Connections

Accelerometer Connection

LIS3DH	CC2650 LAUNCHPAD
CS	VCC
SDO	GND
SCL	DIO4
SDA	DIO5
VCC	VCC
GND	GND
I1	N/C
I2	N/C
A1	N/C
A2	N/C
A3	N/C

SD card connections

SD Reader	CC2650 LAUNCHPAD
CD	GND
DO	DIO8
GND	GND
SCK	DIO10
VCC	3.3V
DI	DIO9
CS	DIO22